



AUTOMATIC CREW SERVE DISPENSER

How to Refill Ice Manually Out of Ice?



Step 1

Open ice loader lid.

- Lift from the recessed handle.
- Swing up and forward.



Step 2

Ensure the lid covers display.

- Lid will protect the display during ice loading.
- Do NOT hang on the ice loader lid.
- The unit will still process orders during ice loading.



Step 3

Fill with ice.

- Rest ice bucket on the ice loader.
- Slowly raise bucket to allow ice to flow into the main hopper.
- Repeat as-needed to fill the main hopper.
- Be sure to use the type of ice specified for the dispenser.



Step 4

Close ice loader lid and clean up.

- Lift and swing the lid back into place.
- Clean any spilled ice in the area.
- Wipe off any moisture on the display screen with a clean microfiber cloth.



**To ensure consistent ice dispense and beverage fill levels,
keep the hopper at least half full.**