

AUTOMATIC CREW SERVE DISPENSER

Out of Cups?


How to Refill Cup Dispenser



Step 1

Confirm cup size to reload.

- If a cup tube is too low to dispense, the size(s) will be highlighted in red on the display graphic.
- Cups can also be refilled before the tube is empty.



Step 2

Pull Handle when not dispensing, to swing cup dispenser.

- Do NOT open the cup dispenser while a cup is being dispensed.
- Cup dispensing will automatically pause.
- The unit will continue adding any new orders to the queue.



Step 3

Remove cups from packaging and inspect.

- Do NOT use damaged or mis-shaped cups.
- Do NOT load previously used or wet cups.

Step 4

Load cups into the matching size tube.

- Refer to the size labels on each tube or the display graphic.
- Slowly push cup sleeve into the dispense tube.
- Do NOT load more than 2 sleeves total in each dispense tube.
- If there is excessive resistance when loading or repeated cup dispense issues, report through correct service channel.



Step 5

Push the handle to fully close the cup dispenser.

- Do NOT put hands behind dispenser while closing to prevent pinching.
- If refilling an empty tube, press the Retry button on the display.
- Any orders in the queue will now process.

